

OPERATION



Wait 20 minutes after the test subject smokes, eats or drinks before testing. Failure to wait 20 minutes can give inaccurate BAC readings and harm the sensor.

Step 1) Place a fitted cover over the mouthpiece each time you test another individual.

Step 2) If it has been more than 24 hours since the device was last used, **prime the sensor** by blowing into the mouthpiece for 4 to 5 seconds **before** turning on the device.

Step 3) **PRESS** the red Power On/Off button located on the front of the unit. A single beep will sound and the device will count down from 99 as it prepares the sensor for testing.

Note: The device will restart a count down from 10 if the sensor is not ready within the first countdown from 99.

Step 4) **WAIT** until the **unit displays “bL”** and you hear a **SINGLE BEEP**.

Note: The device will not shut off until a test is performed OR until 15 seconds of non-use elapses.

Step 5) Take a **DEEP BREATH AND BLOW STEADILY** (for at least 5 seconds) until a **BEEP** sounds to signal completion of the testing.