

F-ER100 - Test Instructions

(Expray is a chemically cumulative testing procedure):

- First wipe the surface with the collection paper (Model #0530). Spray the collection paper with Expray #1 and observe for a dark violet to brown color reaction indicating the presence of Group A explosives.
- Next (~ 30 seconds) spray the same collection paper with Expray #2 and observe for a pink color reaction indicating the presence of Group B explosives.
- Finally, spray the same collection paper with Expray #3 and observe for a crimson pink color reaction indicating the presence of nitrate compounds.

It is recommended that all three Expray cans be sprayed during a testing process even if a positive reaction is observed in either step #1 or #2.

* Even if the environmental surface or package being tested is light in color, the collection paper should still be used.